

Simple installation guild



STEP 1: FLUSH SHOWER FILTER

Flush shower filter to flush out carbon powder in the activated carbon of the cartridge.



STEP 2: INSTALL WITH TEFLON TAPE

Wrap Teflon tape tightly around the threads of your shower filter and shower arm.



STEP 3: PLACE RUBBER O-RINGS

Place two rubber o-rings on both the female and male fittings of the shower filter.



STEP 4: TWIST ON SHOWER HEAD

Twist on shower filter and shower head, then turn clock-wise to tighten by hand.